



TABLE OF CONTENTS

Warning

Table of Contents

Chapter 1 - Getting Started

| | |
|--------------------|-----|
| Introduction | 1-2 |
|--------------------|-----|

Chapter 2 - F2-04AD-1, F2-04AD-1L 4-Channel Analog Current Input

| | |
|--|------|
| F2-04AD-1 | 2-2 |
| Analog Input Configuration Requirements | 2-4 |
| Special Placement Requirements (D2-230 and Remote I/O Bases) | 2-4 |
| Selecting the Number of Channels | 2-6 |
| Wiring Guidelines | 2-7 |
| User Power Supply Requirements | 2-7 |
| Current Loop Transmitter Impedance | 2-8 |
| Wiring Diagram | 2-9 |
| Channel Scanning Sequence (Multiplexing) for a D2-230 CPU | 2-10 |
| Channel Scanning Sequence (Pointer method) for D2-240, D2-250-1, D2-260 or D2-262 CPU | 2-11 |
| Analog Module Updates | 2-11 |
| Understanding the Input Assignments | 2-12 |
| Analog Data Bits | 2-12 |
| Active Channel Indicator Inputs | 2-13 |
| Module Diagnostic Inputs | 2-13 |
| Module Resolution | 2-13 |
| Reading Values: Pointer Method and Multiplexing | 2-14 |
| Pointer Method for D2-240, D2-250-1, D2-260 and D2-262 | 2-14 |

Table of Contents

| | |
|---|------|
| Reading Values (Multiplexing) for D2-230, D2-240, D2-250-1, D2-260 and D2-262 CPUs | 2-16 |
| Single Channel Selected | 2-16 |
| Analog Power Failure Detection | 2-17 |
| Scaling the Input Data..... | 2-17 |
| The Conversion Program..... | 2-18 |
| Analog and Digital Value Conversions..... | 2-18 |
| Filtering Input Noise for D2-250-1, D2-260 and D2-262 CPUs Only | 2-19 |

Chapter 3 - F2-04AD-2, F2-04AD-2L 4-Channel Analog Voltage Input

| | |
|---|-------------|
| Module Specifications | 3-2 |
| F2-04AD-2 | 3-2 |
| F2-04AD-2L is Obsolete..... | 3-2 |
| Analog Input Configuration Requirements..... | 3-2 |
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 3-4 |
| Setting the Module Jumpers | 3-5 |
| Selecting the Number of Channels | 3-5 |
| Selecting the Input Signal Range..... | 3-6 |
| Connecting the Field Wiring | 3-7 |
| Wiring Guidelines | 3-7 |
| User Power Supply Requirements..... | 3-7 |
| Custom Input Ranges | 3-8 |
| Wiring Diagram | 3-9 |
| Module Operation | 3-10 |
| Channel Scanning Sequence (Multiplexing) for a D2-230 CPU..... | 3-10 |
| Channel Scanning Sequence (Pointer method) for D2-240, D2-250-1, D2-260 or D2-262 CPUs | 3-11 |
| Analog Module Updates | 3-11 |
| Understanding Input Assignments | 3-12 |
| Analog Data Bits | 3-12 |
| Active Channel Indicator Inputs | 3-13 |
| Module Diagnostic and Sign Inputs | 3-13 |
| Module Resolution..... | 3-14 |

Writing the Control Program..... 3-15

- Reading Values: Pointer Method and Multiplexing 3-15
- Pointer Method for the D2-240, D2-250-1, D2-260 and D2-262 CPUs 3-15
- Using Bipolar Ranges (Pointer Method) for
D2-240, D2-250-1, D2-260 and D2-262 CPUs..... 3-17
- Reading Values (Multiplexing) for
D2-230, D2-240, D2-250-1, D2-260 and D2-262 CPUs 3-18
- Single Channel Selected 3-19
- Using Bipolar Ranges (Multiplexing) 3-19
- Using 2’s Complement (Multiplexing) for
D2-230, D2-240, D2-250-1, D2-260 and D2-262 CPUs 3-20
- Analog Power Failure Detection 3-21
- Scaling the Input Data..... 3-21
- The Conversion Program..... 3-22
- Analog and Digital Value Conversions..... 3-22
- Filtering Input Noise for D2-250-1, D2-260 and D2-262 CPUs..... 3-23

Chapter 4 - F2-08AD-1, 8-Channel Analog Current Input

- Module Specifications 4-2
- Setting the Module Jumpers 4-5
- Connecting the Field Wiring..... 4-6
- Module Operation 4-9
- Writing the Control Program..... 4-13

Chapter 5 - F2-08AD-2 8-Channel Analog Voltage Input

- Module Specifications 5-2
- Firmware Requirements: 5-2
- Analog Input Configuration Requirements 5-2
- Special Placement Requirements (D2-230 and Remote I/O Bases) 5-4
- Setting the Module Jumpers 5-5
- Selecting the Number of Channels 5-5
- Selecting the Input Voltage..... 5-6
- Connecting the Field Wiring..... 5-7

Table of Contents

| | |
|--|-------------|
| Wiring Guidelines | 5-7 |
| User Power Supply Requirements..... | 5-7 |
| Wiring Diagram | 5-8 |
| Module Operation | 5-9 |
| Channel Scanning Sequence (Multiplexing) for a D2-230 CPU..... | 5-9 |
| Channel Scanning Sequence (Pointer method) for D2-240, D2-250-1, D2-260 or D2-262 CPUs..... | 5-10 |
| Analog Module Updates | 5-10 |
| Understanding the Input Assignments..... | 5-11 |
| Analog Data Bits | 5-11 |
| Active Channel Indicator Inputs | 5-12 |
| Module Resolution..... | 5-13 |
| Writing the Control Program..... | 5-14 |
| Reading Values: Pointer Method and Multiplexing | 5-14 |
| Pointer Method for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 5-14 |
| Using Bipolar Ranges (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 5-16 |
| Reading Values (Multiplexing) for D2-230, D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 5-17 |
| Single Channel Selected | 5-18 |
| Using Bipolar Ranges (Multiplexing) | 5-18 |
| Using 2's Complement (Multiplexing) for D2-230, D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 5-19 |
| Analog Power Failure Detection | 5-20 |
| Scaling the Input Data..... | 5-20 |
| The Conversion Program..... | 5-21 |
| Analog and Digital Value Conversions..... | 5-21 |
| Filtering Input Noise for D2-250-1, D2-260 and D2-262 CPUs..... | 5-22 |

Chapter 6 - F2-04RTD 4-Channel RTD Input

| | |
|---|-----|
| Module Calibration | 6-2 |
| RTD Input Configuration Requirements | 6-2 |
| Input Specifications | 6-3 |
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 6-4 |
| Jumper Locations..... | 6-5 |
| Selecting the Number of Channels | 6-5 |
| Setting Input Type..... | 6-5 |

| | |
|--|------|
| Selecting the Conversion Units..... | 6-6 |
| Wiring Guidelines..... | 6-7 |
| RTD - Resistance Temperature Detector | 6-7 |
| Ambient Variations in Temperature | 6-8 |
| Wiring Diagram..... | 6-8 |
| Channel Scanning Sequence (Multiplexing) for a D2-230 CPU..... | 6-9 |
| Channel Scanning Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 or D2-262 CPUs | 6-10 |
| Analog Module Updates..... | 6-10 |
| Reading Values: Pointer Method and Multiplexing..... | 6-11 |
| Pointer Method for the D2-240, D2-250-1, D2-260 or D2-262 CPUs..... | 6-11 |
| Negative Temperature Readings with Magnitude Plus Sign (Pointer Method) for the D2-240, D2-250-1, D2-260 or D2-262 CPUs..... | 6-13 |
| Magnitude Plus Sign (Binary) | 6-14 |
| Magnitude Plus Sign (BCD)..... | 6-14 |
| Negative Temperatures 2's Complement (Binary/Pointer Method) for the D2-240, D2-250-1, D2-260 or D2-262 CPUs | 6-15 |
| Understanding the Input Assignments (Multiplexing Ladder Only)..... | 6-15 |
| Analog Data Bits..... | 6-16 |
| Active Channel Bits..... | 6-16 |
| Broken Transmitter Bits (Multiplexing Ladder Methods)..... | 6-16 |
| Reading Magnitude Plus Sign Values (Multiplexing)..... | 6-17 |
| Reading 2's Compliment Values (Multiplexing) | 6-18 |
| Scaling the Input Data..... | 6-18 |
| Filtering Input Noise (D2-250-1, D2-260 and D2-262 CPUs Only)..... | 6-19 |

Chapter 7 - F2-04THM 4-Channel Thermocouple Input

| | |
|---|-----|
| Module Specifications..... | 7-2 |
| Module Calibration..... | 7-4 |
| Thermocouple Input Configuration Requirements..... | 7-4 |
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 7-5 |
| Setting the Module Jumpers..... | 7-6 |
| Jumper Locations..... | 7-6 |
| Calibrate Enable..... | 7-6 |
| Selecting the Number of Channels..... | 7-7 |
| Setting Input Type..... | 7-7 |

Table of Contents

| | |
|--|-------------|
| Selecting the Conversion Units..... | 7-8 |
| Thermocouple Conversion Units..... | 7-8 |
| Voltage Conversion Units..... | 7-8 |
| Connecting the Field Wiring..... | 7-9 |
| Wiring Guidelines..... | 7-9 |
| User Power Supply Requirements..... | 7-9 |
| Thermocouples..... | 7-10 |
| Ambient Variations in Temperature..... | 7-10 |
| Wiring Diagrams..... | 7-11 |
| Module Operation..... | 7-13 |
| Channel Scanning Sequence (Multiplexing) for a D2-230 CPU..... | 7-13 |
| Channel Scanning Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 7-14 |
| Analog Module Updates..... | 7-14 |
| Writing the Control Program..... | 7-15 |
| Reading Values Pointer Method and Multiplexing..... | 7-15 |
| Pointer Method for the D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 7-15 |
| Negative Temperature Readings with Magnitude Plus Sign (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 7-17 |
| Magnitude Plus Sign (Binary)..... | 7-17 |
| Magnitude Plus Sign (BCD)..... | 7-18 |
| Negative Temperatures 2's Complement (Binary/Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 7-19 |
| Understanding the Input Assignments (Multiplexing Ladder Only)..... | 7-19 |
| Analog Data Bits..... | 7-20 |
| Active Channel Bits..... | 7-20 |
| Broken Transmitter Bits (Pointer and Multiplexing Ladder Methods)..... | 7-20 |
| Reading Magnitude Plus Sign Values (Multiplexing)..... | 7-21 |
| Reading 2's Compliment Values (Multiplexing)..... | 7-22 |
| Scaling the Input Data..... | 7-22 |
| Module Resolution 16-Bit (Unipolar Voltage Input)..... | 7-23 |
| Module Resolution 15-Bit Plus Sign(Bipolar Voltage Input)..... | 7-23 |
| Analog and Digital Value Conversions..... | 7-24 |
| Filtering Input Noise (D2-250-1, D2-260 and D2-262 CPUs Only)..... | 7-25 |

Chapter 8 - F2-02DA-1,F2-02DA-1L 2-Channel Analog Current Output

| | |
|--|------|
| Analog Output Configuration Requirements..... | 8-2 |
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 8-4 |
| Wiring Guidelines..... | 8-5 |
| User Power Supply Requirements..... | 8-5 |
| Wiring Diagram..... | 8-6 |
| Load Range..... | 8-6 |
| Channel Scanning Sequence (Multiplexing) for a D2-230 CPU..... | 8-7 |
| Channel Scanning Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs | 8-8 |
| Understanding the Output Assignments..... | 8-9 |
| Channel Select Outputs..... | 8-9 |
| Analog Data Bits..... | 8-10 |
| Module Resolution..... | 8-10 |
| Writing Values: Pointer Method and Multiplexing..... | 8-11 |
| Pointer Method for the D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 8-11 |
| Writing Data (Multiplexing)..... | 8-13 |
| Write Data to One Channel..... | 8-14 |
| Write Data to Both Channels..... | 8-14 |
| Calculating the Digital Value..... | 8-15 |
| Analog and Digital Value Conversions..... | 8-15 |
| The Conversion Program..... | 8-16 |

Chapter 9 - F2-02DA-2, F2-02DA-2L, 2-Channel Analog Voltage Output

| | |
|---|-------------|
| Module Specifications | 9-2 |
| Analog Output Configuration Requirements..... | 9-2 |
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 9-4 |
| Setting the Module Jumpers | 9-5 |
| Voltage Range and Output Combinations..... | 9-6 |
| Connecting and Disconnecting the Field Wiring | 9-8 |
| Wiring Guidelines..... | 9-8 |
| User Power Supply Requirements..... | 9-8 |
| Wiring Diagram..... | 9-9 |
| Module Operation | 9-10 |
| Channel Scanning Sequence (Multiplexing) for a D2-230 CPU..... | 9-10 |

Table of Contents

| | |
|--|-------------|
| Channel Scanning Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs | 9-11 |
| Understanding the Output Assignments..... | 9-12 |
| Channel Select Outputs | 9-12 |
| Analog Data Bits | 9-13 |
| Signal Sign Output..... | 9-13 |
| Bipolar Output Data | 9-13 |
| Module Resolution..... | 9-14 |
| Writing the Control Program..... | 9-15 |
| Calculating the Digital Value..... | 9-15 |
| The Conversion Program..... | 9-16 |
| Negative Values with Bipolar Range..... | 9-17 |
| Writing Values: Pointer Method and Multiplexing..... | 9-18 |
| Writing Values (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 9-18 |
| Writing Data (Multiplexing)..... | 9-20 |
| Write Data to One Channel..... | 9-22 |
| Write Data to Both Channels..... | 9-22 |
| Analog and Digital Value Conversions..... | 9-23 |

Chapter 10 - F2-08DA-1, 8-Channel Analog Current Output

| | |
|--|-------------|
| Module Specifications | 10-2 |
| Firmware Requirements:..... | 10-2 |
| Analog Output Configuration Requirements..... | 10-2 |
| Special Placement Requirements (D2-230 and Remote I/O Bases) | 10-4 |
| Connecting and Disconnecting the Field Wiring | 10-5 |
| Wiring Guidelines | 10-5 |
| User Power Supply Requirements..... | 10-5 |
| Wiring Diagram..... | 10-6 |
| Load Range | 10-6 |
| Module Operation | 10-7 |
| Channel Scanning Sequence (Multiplexing) for a D2-230 CPU..... | 10-7 |
| Channel Scanning Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs | 10-8 |
| Understanding the Output Assignments..... | 10-8 |
| Channel Select Outputs | 10-9 |

| | |
|--|--------------|
| Analog Data Bits | 10-10 |
| Output Enable..... | 10-10 |
| Module Resolution..... | 10-10 |
| Writing the Control Program..... | 10-11 |
| Calculating the Digital Value..... | 10-11 |
| The Conversion Program..... | 10-11 |
| Writing Values: Pointer Method and Multiplexing..... | 10-12 |
| Pointer Method for the D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 10-12 |
| Writing Data (Multiplexing Example) | 10-14 |
| Write Data (Multiplexing Example) Continued..... | 10-15 |
| Write Data to One Channel..... | 10-16 |
| Analog and Digital Value Conversions..... | 10-16 |

Chapter 11 - F2-08DA-2, 8-Channel Analog Voltage Output

| | |
|---|-------------|
| Module Specifications | 11-2 |
| Firmware Requirements: | 11-2 |
| Analog Output Configuration Requirements..... | 11-3 |
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 11-4 |
| Setting the Module Jumpers | 11-5 |
| Voltage Range and Output Combinations..... | 11-5 |
| Connecting the Field Wiring..... | 11-6 |
| Wiring Guidelines..... | 11-6 |
| User Power Supply Requirements..... | 11-6 |
| Wiring Diagram..... | 11-7 |
| Module Operation | 11-8 |
| Channel Update Sequence (Multiplexing) for a D2-230 CPU | 11-8 |
| Channel Update Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 11-9 |
| Understanding the Output Assignments..... | 11-10 |
| Channel Select Outputs | 11-10 |
| Analog Data Bits | 11-11 |
| Output Enable..... | 11-11 |
| Module Resolution..... | 11-11 |

Table of Contents

| | |
|--|-------|
| Writing the Control Program | 11-12 |
| Calculating the Digital Value..... | 11-12 |
| The Conversion Program..... | 11-13 |
| Writing Values: Pointer Method and Multiplexing..... | 11-14 |
| Pointer Method for the D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 11-14 |
| Writing Data Example (Multiplexing)..... | 11-16 |
| Write Data to One Channel..... | 11-18 |
| Analog and Digital Value Conversions..... | 11-18 |

Chapter 12 - F2-02DAS-1, 4–20 mA Isolated 2-Channel Analog Current Output

| | |
|---|-------|
| Module Specifications | 12-2 |
| Firmware Requirements:..... | 12-2 |
| Analog Output Configuration Requirements..... | 12-3 |
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 12-4 |
| Connecting the Field Wiring | 12-5 |
| Wiring Guidelines..... | 12-5 |
| Loop Power Supply Requirements..... | 12-5 |
| Wiring Diagram..... | 12-6 |
| Module Operation | 12-7 |
| Channel Update Sequence (Multiplexing) for a D2-230 CPU..... | 12-7 |
| Channel Update Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 12-8 |
| Understanding the Output Assignments..... | 12-9 |
| Channel Select Outputs..... | 12-9 |
| Analog Data Bits..... | 12-10 |
| Module Resolution..... | 12-10 |
| Writing the Control Program | 12-11 |
| Calculating the Digital Value..... | 12-11 |
| Engineering Units Conversion..... | 12-12 |
| Writing Values: Pointer Method and Multiplexing..... | 12-13 |
| Pointer Method for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 12-13 |
| Write Data Example (Multiplexing)..... | 12-15 |
| Write Data to One Channel..... | 12-16 |

| | |
|---|-------|
| Write the same Data to Both Channels..... | 12-16 |
| Analog and Digital Value Conversions..... | 12-17 |

Chapter 13 - F2-02DAS-2, 0-5V, 0-10V, 2-Channel Isolated Analog Output

| | |
|--|--------------|
| Module Specifications | 13-2 |
| Firmware Requirements:..... | 13-2 |
| Analog Output Configuration Requirements | 13-3 |
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 13-4 |
| Setting the Module Jumpers | 13-5 |
| Connecting the Field Wiring..... | 13-6 |
| Wiring Guidelines | 13-6 |
| Transmitter Power Supply Requirements..... | 13-6 |
| Wiring Diagram..... | 13-7 |
| Module Operation..... | 13-8 |
| Channel Update Sequence (Multiplexing) for a D2-230 CPU | 13-8 |
| Channel Update Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs | 13-9 |
| Understanding the Output Assignments..... | 13-9 |
| Channel Select Outputs..... | 13-10 |
| Analog Data Bits..... | 13-10 |
| Module Resolution..... | 13-11 |
| Writing the Control Program..... | 13-12 |
| Calculating the Digital Value..... | 13-12 |
| Engineering Units Conversion..... | 13-13 |
| Writing Values: Pointer Method and Multiplexing..... | 13-14 |
| Pointer Method for the D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 13-14 |
| Write Data Example (Multiplexing) | 13-16 |
| Write Data to One Channel..... | 13-17 |
| Write the same Data to Both Channels..... | 13-17 |
| Analog and Digital Value Conversions..... | 13-18 |

Chapter 14 - F2-4AD2DA, 4-Ch. In / 2-Ch. Out Analog Combination

| | |
|---|-------------|
| Module Specifications | 14-2 |
| Combination Analog Configuration Requirements | 14-3 |

Table of Contents

| | |
|---|--------------|
| Special Placement Requirements (D2-230 and Remote I/O Bases)..... | 14-4 |
| Connecting the Field Wiring..... | 14-5 |
| Wiring Guidelines..... | 14-5 |
| Loop Power Supply Requirements..... | 14-5 |
| Current Loop Transmitter Impedance..... | 14-6 |
| Wiring Diagram..... | 14-7 |
| Module Operation..... | 14-8 |
| Input Channel Scanning Sequence (Multiplexing) for a D2-230 CPU..... | 14-8 |
| Input Channel Scanning Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 14-8 |
| Output Channel Update Sequence (Multiplexing) for a D2-230 CPU..... | 14-9 |
| Output Channel Update Sequence (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 14-9 |
| Understanding the I/O Assignments..... | 14-10 |
| Input Data Bits..... | 14-10 |
| Active Channel Indicator Bits..... | 14-11 |
| Diagnostic Indicator Inputs..... | 14-11 |
| Output Data Bits..... | 14-11 |
| Output Channel Selection Bits..... | 14-12 |
| Module Resolution..... | 14-12 |
| Writing the Control Program..... | 14-13 |
| Analog Input Failure Detection..... | 14-13 |
| Calculating the Digital Value..... | 14-13 |
| Scaling the Input Data..... | 14-15 |
| Read / Write Program (Pointer Method) for D2-240, D2-250-1, D2-260 and D2-262 CPUs..... | 14-16 |
| Read Input Values (Multiplexing)..... | 14-18 |
| Single Input Channel Selected (Multiplexing)..... | 14-19 |
| Write Output Values (Multiplexing)..... | 14-19 |
| Write Data to One Channel..... | 14-20 |
| Write the same Data to Both Channels..... | 14-20 |
| Analog and Digital Value Conversions..... | 14-20 |
| Filtering Input Noise (D2-250-1, D2-260 and D2-262 CPUs Only)..... | 14-21 |

Chapter 15 - F2-8AD4DA-1, 8-Ch. In / 4-Ch. Out Analog Current Combination

| | |
|---|--------------|
| Module Specifications | 15-2 |
| F2-8AD4DA-1 Requirements..... | 15-2 |
| Module Placement and Configuration Requirements..... | 15-5 |
| Connecting the Field Wiring | 15-6 |
| Wiring Guidelines..... | 15-6 |
| User Power Supply Requirements..... | 15-6 |
| Current Loop Transmitter Impedance | 15-7 |
| Wiring Diagram..... | 15-8 |
| Module Operation | 15-9 |
| Input Channel Scanning Sequence (Pointer Method)..... | 15-9 |
| Output Channel Update Sequence (Pointer Method)..... | 15-10 |
| Understanding the I/O Assignments..... | 15-11 |
| Input Data Bits..... | 15-12 |
| Output Data Bits..... | 15-12 |
| Special V-Memory Locations | 15-13 |
| Module Configuration Registers | 15-13 |
| Number of I/O Channels Enabled & Data Format..... | 15-14 |
| Input Selection Resolution Bits..... | 15-14 |
| Input Track and Hold Selection Bits..... | 15-15 |
| Writing the Control Program | 15-16 |
| Configuring the Module to Read/Write I/O (Pointer Method) for D2-250-1, D2-260 and D2-262..... | 15-16 |
| Module Configuration Example 1:..... | 15-17 |
| Module Configuration Example 2:..... | 15-18 |
| Module Configuration Example 3:..... | 15-19 |
| Module 12-bit Input Resolution..... | 15-20 |
| Module 14-bit Input Resolution..... | 15-20 |
| Module 16-bit Input Resolution..... | 15-20 |
| Analog and Digital Input Data Value Conversion..... | 15-21 |
| Input Value Comparisons: Analog, Digital, Engineering Units | 15-21 |
| Scaling the Input Data..... | 15-22 |
| Scaling Example | 15-22 |

Table of Contents

| | |
|--|-------|
| Input Engineering Unit Conversion Example 1:..... | 15-23 |
| Input Engineering Unit Conversion Example 2:..... | 15-23 |
| Input Engineering Unit Conversion Example 3:..... | 15-24 |
| Input Engineering Unit Conversion Example 4:..... | 15-25 |
| Using the Input Track and Hold Feature..... | 15-25 |
| Track and Hold Example:..... | 15-26 |
| Module 16-bit Output Resolution | 15-27 |
| Digital and Analog Output Data Value Conversion..... | 15-27 |
| Output Value Comparisons: Analog, Digital, Engineering Units | 15-27 |
| Calculating the Digital Output Value..... | 15-28 |
| Calculating Output Data: Engineering Units Conversion | 15-28 |
| Output Engineering Unit Conversion / Output Data Calculation Example:..... | 15-28 |

Chapter 16 - F2-8AD4DA-2, 8-Ch. In / 4-Ch. Out Analog Voltage Combination

| | |
|--|--------------|
| Module Specifications | 16-2 |
| F2-8AD4DA-2 Hardware and Firmware Requirements..... | 16-2 |
| Module Placement and Configuration Requirements | 16-5 |
| Connecting the Field Wiring..... | 16-6 |
| Wiring Guidelines | 16-6 |
| User Power Supply Requirements..... | 16-6 |
| Wiring Diagram | 16-7 |
| Module Operation | 16-8 |
| Input Channel Scanning Sequence (Pointer Method) | 16-8 |
| Output Channel Update Sequence (Pointer Method) | 16-9 |
| Understanding the I/O Assignments..... | 16-10 |
| Input Data Bits..... | 16-11 |
| Output Data Bits | 16-11 |
| Special V-Memory Locations..... | 16-12 |
| Module Configuration Registers | 16-12 |
| Number of I/O Channels Enabled & Data Format..... | 16-13 |
| Input Selection Resolution Bits | 16-13 |
| Input and Output Range Selection Bits..... | 16-14 |
| Input Track and Hold Selection Bits..... | 16-15 |

Writing the Control Program..... 16-16

- Configuring the Module to Read/Write I/O (Pointer Method) for
D2-250-1, D2-260 and D2-262.....16-16
- Module Configuration Example 1:.....16-17
- Module Configuration Example 2:.....16-18
- Module Configuration Example 3:.....16-19
- Module 12-bit Input Resolution.....16-20
- Module 14-bit Input Resolution.....16-20
- Module 16-bit Input Resolution.....16-20
- Analog and Digital Input Data Value Conversion.....16-21
- Scaling the Input Data.....16-22
- Scaling Example16-22
- Input Engineering Unit Conversion Example 1:.....16-23
- Input Engineering Unit Conversion Example 2:.....16-23
- Input Engineering Unit Conversion Example 3:.....16-24
- Using the Input Track and Hold Feature.....16-24
- Track and Hold Example:.....16-25
- Module 16-bit Output Resolution16-26
- Digital and Analog Output Data Value Conversion.....16-26
- Output Value Comparisons: Analog, Digital, Engineering Units16-26
- Calculating the Digital Output Value.....16-27
- Calculating Output Data: Engineering Units Conversion16-27

Appendix A - DL205 Discrete I/O Memory Map

- Input (X) / Output (Y) Bit Map.....A-2
- Control Relay Bit MapA-4
- Remote I/O Bit Map (D2-260 and D2-262 only)A-8