



# TABLE OF CONTENTS

---

## Introduction

BRX Introduction.....	ii
Conventions Used.....	iii
BRX Overview.....	iv
BRX Platform.....	v

## Chapter 1: General Installation and Wiring Guidelines

Safety Guidelines.....	1-2
Introduction to the BRX Mechanical Design.....	1-5
Dimensions and Installation.....	1-6
Mounting Guidelines.....	1-10
Wiring Guidelines.....	1-15
I/O Module Wiring Options.....	1-24
System Wiring Strategies.....	1-26

## Chapter 2: BX ME Wiring

BX ME Micro PLC Unit (MPU) Overview.....	2-2
BX-DM1E-M Wiring.....	2-4
BX-DM1E-M-D Wiring.....	2-6

## Chapter 3: BX 10/10E Wiring

BX 10/10E Micro PLC Unit (MPU) Overview.....	3-2
BX 10 Micro PLC Units (MPUs).....	3-8
BX 10E Micro PLC Units (MPUs).....	3-31

## Chapter 4: BX 18/18E Wiring

BX 18/18E Micro PLC Units (MPUs) Overview.....	4-2
BX 18 Micro PLC Units (MPUs).....	4-9
BX 18E Micro PLC Units (MPUs).....	4-50

## Chapter 5: BX 36/36E Wiring

BX 36/36E Micro PLC Units (MPUs) Overview.....	5-2
BX 36 Micro PLC Units (MPUs).....	5-9
BX 36E Micro PLC Units (MPUs).....	5-50

**Chapter 6: BRX Pluggable Option Module (POM)**

Overview.....	6-2
BX-P-SER2-TERM .....	6-4
BX-P-SER2-TERMFC .....	6-5
BX-P-SER422-TERM .....	6-6
BX-P-SER4-TERM .....	6-7
BX-P-SER2-RJ12 .....	6-8
BX-P-ECOMLT .....	6-9
BX-P-ECOMEX .....	6-10
BX-P-OPCUA .....	6-11
BX-P-SPARK .....	6-12
BX-P-USB-B.....	6-13
BX-P-USB-C.....	6-13

**Chapter 7: BRX Digital I/O Expansion Modules**

Overview.....	7-2
Module Types.....	7-3
Wiring Termination Options.....	7-5
General Specifications.....	7-8
Module Installation .....	7-8
BX-xxNF3 Sinking/Sourcing 3–5 VDC Input.....	7-9
BX-xxND3 Sinking/Sourcing 12–24 VDC Input.....	7-10
BX-xxNB 12–24 VAC Input .....	7-13
BX-xxNA 120–240 VAC Input .....	7-15
BX-16NN Sinking/Sourcing 48 VDC Input.....	7-17
BX-08SIM Simulator Input .....	7-18
BX-xxTD1 Sinking 12–24 VDC Output .....	7-19
BX-xxTD2 Sourcing 12–24 VDC Output .....	7-22
BX-16TF2 Sourcing 3–5 VDC Output .....	7-25
BX-16TD2W Sourcing 12–24 VDC Output with Diagnostics.....	7-26
BX-16TDY2 Sourcing 12–24 VDC Output .....	7-27
BX-16TN2 Sourcing 48–60 VDC Output.....	7-28
BX-xxTR Relay Output .....	7-29
BX-xxTRZ Relay Output.....	7-31
BX-05TRS Relay Output .....	7-32
BX-05TRS-1 Relay Output .....	7-33
BX-xxTA 120–240 VAC Output .....	7-34
BX-08CD3R Combination DC Input/Relay Output.....	7-36
BX-xxCD3D1 Combination DC Input/Sinking DC Output.....	7-38
BX-xxCD3D2 Combination DC Input/Sourcing DC Output.....	7-41
BX-16CF3F2 Combination DC Input/DC Sourcing Output.....	7-44
BX-8NN8TN2 Combination DC Input/DC Sourcing Output .....	7-46

## Chapter 8: BRX Analog I/O Expansion Modules

Overview.....	8-2
Module Types.....	8-2
Wiring Termination Options.....	8-5
General Specifications.....	8-8
Dimensional Information.....	8-9
Module Installation .....	8-9
Module Configuration.....	8-10
Analog Tips and Troubleshooting .....	8-11
BX-04ADM-1 Analog Current Sinking Input .....	8-18
BX-xxAD-1 Analog Current Sinking Input .....	8-23
BX-xxAD-2B Analog Voltage Input .....	8-30
BX-xxAD-3 Universal Analog Input .....	8-37
BX-xxTHM Thermocouple Input .....	8-41
BX-06RTD Resistance Temperature Detector Input .....	8-47
BX-08NTC Thermistor Input .....	8-53
BX-xxUT Universal Temperature Input .....	8-58
BX-xxDA-1 Analog Current Source Output .....	8-64
BX-xxDA-2B Analog Voltage Output .....	8-69
BX-xxDA-3 Universal Analog Output .....	8-74
BX-xADxDA-1 Combination Analog Current Input/Output.....	8-77
BX-xADxDA-2B Combination Analog Voltage Input/Output .....	8-81
BX-xADxDA-3 Universal Combination Analog Input/Output .....	8-85
BX-4RTD4DA-1 Combination RTD Input/Current Output.....	8-91
BX-4THM4DA-1 Combination Thermocouple Input/Current Output.....	8-96
BX-4UT4DA-3 Universal Temperature Input/Analog Output .....	8-101
BX-4UT4TD1 Universal Temperature Input/ DC Sinking Output .....	8-109
BX-4UT4TD2 Universal Temperature Input/ DC Sourcing Output .....	8-116
BX-4UT4TR Universal Temperature Input/ Relay Output .....	8-123

## Chapter 9: BRX Motion Control, Communications & Specialty Modules

Overview.....	9-2
Module Types.....	9-2
Wiring Termination Options.....	9-4
General Specifications.....	9-6
Dimensional Information.....	9-6
Module Installation .....	9-7
Module Configuration.....	9-8
BX-HSIO1 and BX-HSIO2 High Speed Input/Output Modules .....	9-9
BX-HSIO4 High Speed Input/Output Module .....	9-11
BX-HSIOx High Speed I/O Modules Setup.....	9-16

BX-SERIO Serial Communications Module .....	9-17
BX-SERIO-2 Serial Communications Module .....	9-20
BX-SERIO-4 Serial Communications Module .....	9-23
BX-APAD Active Filling Module .....	9-26

## Chapter 10: BRX Do-more! CPU Specifications

The BRX Platform .....	10-2
Do-more! Designer Software .....	10-3
BRX Do-more! CPU Common Specifications.....	10-3
Battery Replacement.....	10-10
microSD Slot .....	10-11
Customizing the Logo Window.....	10-12
Replacing Access Covers.....	10-13
RS-232/485 Port Specifications.....	10-14
Ethernet Port Specifications .....	10-16
POM Slot.....	10-16

## Chapter 11: BRX Do-more! Motion Control and High-speed I/O

Overview.....	11-2
BRX Wiring Examples: High-Speed Inputs .....	11-5
BRX Wiring Examples: High-speed Outputs .....	11-10
Available High-Speed Input and Output Features.....	11-18
Access Setup High Speed I/O page .....	11-19
BRX High-Speed Examples .....	11-50
BRX High-speed Instructions .....	11-69

## Chapter 12: BRX Do-more! Serial Communications

Overview.....	12-2
Troubleshooting Serial Communications .....	12-4
Communications Design.....	12-5
USB Communications.....	12-9
Serial Communications .....	12-9
General Serial Specifications.....	12-10
Serial Port Setup and Programming.....	12-17
Serial Protocols.....	12-20

## Chapter 13: BRX Do-more! Ethernet Communications

Overview.....	13-2
Troubleshooting Ethernet Communications.....	13-6
Communications Design.....	13-8
Ethernet.....	13-13
Ethernet Protocols .....	13-23

**Chapter 14: BRX Remote I/O: BX-DMIO, BX-EBC100 & GS-EDRV100**

What it is.....	14-2
BX-DMIO & BX-EBC100 I/O Controllers .....	14-3
AC Power Wiring (BX-DMIO-M & BX-EBC100-M) .....	14-6
DC Power Wiring (BX-DMIO-M-D & BX-EBC100-M-D).....	14-7
Ethernet Communications .....	14-8
DIP Switch Specifications .....	14-8
Status Indicators.....	14-9
Supported Modules.....	14-10
Configuration .....	14-11
GS-EDRV100 .....	14-21

**Chapter 15: BX-MBIO Modbus I/O Controller**

Overview.....	15-2
BX-MBIO I/O Controllers .....	15-3
Configuration .....	15-8
DIP Switch Specifications .....	15-8
Status Indicators.....	15-9
Modbus Protocol Function Codes Supported by BX-MBIO.....	15-10
Modbus Protocol Exception Responses .....	15-13
Modbus RTU, Serial Communications.....	15-15
Modbus TCP, Ethernet Communications .....	15-20
BX-MBIO Configuration.....	15-20
Troubleshooting with Modbus Poll .....	15-34
Additional BX-EBC100 and BX-MBIO Modbus Mapping Information.....	15-45

**Appendix A: BRX Do-more! Maintenance and Troubleshooting**

Hardware Maintenance .....	A-2
Diagnostics.....	A-3
CPU Indicators.....	A-5
PWR Indicator .....	A-6
RUN Indicator .....	A-7
ERR Indicator.....	A-7
Communications Problems.....	A-7
I/O Troubleshooting .....	A-8
Noise Troubleshooting .....	A-10

**Appendix B: EU Directives (CE)**

European Union (EU) Directives.....	B-2
Basic EMC Installation Guidelines.....	B-5

**Appendix C: BRX MPU Power Budgeting**

BRX MPU Power Budget..... C-2

**Appendix D: Error Codes and System Locations**

Do-more! Designer Errors and System Locations ..... D-2

**Appendix E: NetEdit—Ethernet Setup Utility for HOST Automation Products**

Basic Ethernet wiring and setup.....E-2

NetEdit 3 Software .....E-4

**Appendix F: Tips & Tricks**

Tips & Tricks .....F-2

**Appendix G: Online Resources**

Online Resources .....G-2